


Installation Instructions for 240 VAC motor Series

www.crestmi.com.au



Environmental Considerations

- The motor is rated for continuous use and the larger motors use a cooling fan to move air across the sealed motor body. Do not obstruct the cooling path in any way.
- Do not use this motor in wet areas without properly protecting the installation from contact with moisture. Observe the same precautions as with any electrical installation where water or other conductive fluids could cause or lead to a shock hazard.


Electrical Connection

- This motor is designed for operation on the single phase Australian mains supply of 230-240VAC 50 Hz. Do not connect it to any other supply.
- The capacitor is an essential part of the motor circuit and must be connected across the WHITE and BLUE wires. It <u>must not</u> be disconnected or left out of the circuit under any circumstances. Its replacement must be of the same value as the original. Unless otherwise requested, the motor is shipped with the capacitor already soldered in place.
- The **RED** wire is connected to the supply **ACTIVE**
- The BLUE wire is connected to the supply NEUTRAL for CCW rotation OR .. (Note Or)

Tachometer Outputs to US22B Speed Controller (Not Connected if no US22B) Green - To Earth Red - To Active White (Not Connected) Blue - To Neutral

Connection for CCW Motor Rotation

Note: The <u>Gearhead</u> ratios from 12.5 to 18 and 90 to 200 yield an opposite rotation on the output shaft.



Connection for CW Motor Rotation

Note: The <u>Gearhead</u> ratios from 12.5 to 18 and 90 to 200 yield an opposite rotation on the output shaft.

- The WHITE wire is connected to the supply NEUTRAL for CW rotation
- Important Note: Do not connect the WHITE and BLUE together. Connect the supply NEUTRAL to one or the other. Do not connect ACTIVE to either WHITE or BLUE under any circumstances.
- For complete safety, an EARTH connection is provided to the motor body and should be included when connecting to the mains supply. The lack of an EARTH connection will not affect the operation of the motor, but like all mains connected, metal bodied machine parts, the EARTH connection is mandated for safety.
- Two small Cream coloured wires are tachometer outputs for use with the **US22B** electronic speed controllers and unless implemented, are not used.

